

Coherent and non-coherent detection requires carrier phase recovery at the receiver and hence, circuits to perform phase estimation. Source of carrier-phase mismatch at the receiver: Coherent
???????????????????? detection