

The surface prepared to receive the materials for building a railway track, such as ballast, sleepers, and rails, is known as the formation or subgrade