Trommel: o The material to be screened is fed at the	e upper end and gradually moves down the
	.screening surface towards the lower end