

In contrast, PAM, PWM, and PPM are more susceptible to noise, as variations in amplitude, width, or position can be misinterpreted as signal changes