

Cover the bottles with paper or aluminum foil and tie it on with the string. Alternatively, sample bottles. 1
can be sterilized by heating in a dry oven at 170°C for 1 hour. Wash the sample bottle with distilled or
.de-ionized water. 2.3.4.5