

As the system is heated at constant pressure, the temperature increases considerably while the specific volume increases slightly. Eventually, the system is brought to the state represented by f (highlighted by the black dot). This is the saturated liquid state corresponding to the specified pressure.