

Although beacons are regularly broadcast by an AP, the probe, authentication, and association frames are generally used only during the association and re-association process. In a CUWN network, the APs advertise their presence in the network by sending out Beacon frames, which includes the SSID and BSSID information.