

Weigh out the cement, sand, coarse aggregate and water separately as mentioned in the concrete mix design. Place the weighted quantities of coarse aggregate, fine aggregate and the cement in the pan or mixer. Fill the moulds (cube/cylinder) with obtained concrete in three layers of equal height (approximately 50 mm). Each layer shall be uniformly tamped over the. the resulting concrete is of uniform color and proper workability.