

1. Cover the bottles with paper or aluminum foil and tie it on with the string. Alternatively, sample bottles can be sterilized by heating in a dry oven at 170°C for 1 hour. Wash the sample bottle with distilled or de-ionized water. 2. 3. 4. 5.