

Press the power button, the "ice making" indicator light is always on, and then the ice blocks will be made automatically. After the ice making is completed, the defrosting process will be carried out, and then the snow shoveling function will be entered, and so on. When the "add water" light turns red, it means that there is a shortage of water in the water tank