

Pulling the #1 ENG EMER OFF T-handle closes the T-handle switch. Setting the FIRE EXTGH switch S20 to MAIN supplies control voltages directly into the logic module. This applies 28 vdc to the fire extinguisher logic module, arming the system