

Explanation of the Code: `analogRead(FSRPin)`: Reads the analog voltage from the FSR connected to .pin A0.
`delay(500)`: Adds a half-second delay between readings to make the data more readable