

Open lid of hot water vessel and fill up water at about half of the vessel. Heat the water by electrical heater for about 10 minutes. Switch off the electrical heater supply. Calculate error percentage of k-type, pt-100 type thermocouple and thermistor. 2.3.4.5.6.7.8.