

Here's how it works: The chilled water, which is really cold, flows through the cooling coil. As the warm air passes over the coil, the cold coil absorbs the heat from the air. This causes the chilled water to warm up a bit, while the air gets cooler.