

A piston is fitted to each cylinder and used to receive gas pressure and transmit the explosion to the crankshaft.